
flexi™ STORAGE | CLEVER CUBE

2X4 CUBE STAND
ASSEMBLY INSTRUCTIONS





CARE INSTRUCTIONS: We recommend to wipe over with a damp cloth to remove any dust.
Avoid using any cleaning chemicals as this may cause damage to the surface.


flexi STORAGE | CLEVER CUBE


2X4 CUBE STAND
ASSEMBLY INSTRUCTIONS


ELEMENTS













flexi™ STORAGE | CLEVER CUBE

2X4 CUBE STAND
ASSEMBLY INSTRUCTIONS

STEP 1




x2




x2

STEP 2




STEP 3




flexi STORAGE | CLEVER CUBE

2X4 CUBE STAND
ASSEMBLY INSTRUCTIONS



OR



WARNING: THIS PRODUCT IS DESIGNED TO BE USED WITH FLEXI STORAGE CLEVER CUBE AND PRACTA SOLUTIONS CUBE STORAGE UNITS. THIS CUBE STAND CAN HOLD A MAXIMUM LOAD OF 150 KG.

Once the cube storage unit is placed on top of the cube stand, ensure that the correct wall mount and fixing hardware are securely fitted to prevent toppling. We strongly recommend that this product be permanently fixed to the wall or other suitable surface. Wall mount and fixing hardware is not included, as different surface materials require different types of attachments. Please seek professional advice if you are unsure which fixing hardware is suitable for your wall or surface. Regularly check the fixing device to ensure it remains secure.
Do not exceed the 150 kg maximum load capacity of the cube storage unit. Evenly distribute loads throughout the shelves and place heavier items on the lower shelves.

flexistorage.com.au
flexistorage.co.nz
MADE IN CHINA
Distributed by:
Visy Retail Services Pty Ltd (AU): 1300 734 714
Visy Board Limited (NZ): 0800 443 058